


NEX-PROBETESTER2




- Quickly test all Tektronix TLA5000/600/700 General Purpose, Mictor, and Compression probes.
- Activity Mode allows quick testing of a single probe via the TLA's Activity Indicator window.
- Acquisition Mode allows for quick testing of multiple probes of the same type by inspecting TLA acquisitions.
- Testing is simple and easily verifiable. A high signal is walked across 16 normally low channels and a low is walked across 16 normally high channels. The clock/qualifier lines are inverted to one another and are center aligned in the valid data window.
- Probes supported include:
 - P6434 34-channel High-Density Mictor Probe
 - P6417 17-channel General Purpose probe: single-ended
 - P6418 17-channel General Purpose probe: single-ended
 - P6419 17-channel Compression Probe: single-ended
 - P6810 34-channel General Purpose probe: single-ended or differential
 - P6860 17-channel Compression Probe: single-ended
 - P6880 17-channel Compression Probe: differential
 - P6960 34-channel D-Max High-Density Connectorless: single-ended
 - P6980 34-channel D-Max High-Density Connectorless: differential


General Description

NEX-PROBETESTER allows for quick testing of Tektronix Logic Analyzer probes using the provided board and a TLA. The probe tester is capable of testing all 32 data channels of a probe along with both of its clock/qualifier (C/Q) lines. Depending on the probe tested, this requires hooking up one or more probe heads. The test itself drives 16 data lines low and then proceeds to walk a high to each data channel, starting with the LSB. The other 16 data lines are driven high and the test then walks a low to each channel. The C/Q lines are driven to opposite values with a pulse on each in the center of the valid data window. This allows for synchronous acquisition on either edge using either C/Q line. Asynchronous acquisition is also possible. Two testing modes are provided:


Activity Mode slows data transitioning down so that data can be visually verified using the TLA Application Software's Activity Indicator window.



Acquisition Mode allows quick verification of data by taking a TLA acquisition.



Silkscreen



Tektronix Logic Analyzer Support / Configuration

TLA600/700 Logic Analyzer

- P6434, P6417, P6418, P6419, P6810, P6860, P6880, P6960 or P6980 probes

Ordering / Contact Information

Part Number NEX-PROBETESTER2

Includes: NEX-PROBETESTER2 board
Software
Manual
Qty. 3 AA Batteries

Postal: Nexus Technology, Inc.
78 Northeastern Blvd. #2
Nashua, NH 03062

Telephone: 877-595-8116

Fax: 877-595-8118

Email: support@nexustechnology.com
quotes@nexustechnology.com
techsupport@nexustechnology.com

Website: www.nexustechnology.com

Placing an Order

Credit Card orders can be placed directly at 877-595-8116.
Purchase orders can be faxed to 877-595-8118.

Nexus Technology, Inc. reserves the right to make changes in design or specification at any time without notice. Nexus Technology, Inc. does not assume responsibility for use of any circuitry described. All trademarks are the property of their respective owners.